


# Spare part lists / Connecting diagram



## Spare part lists

Sheet

WCH 1092 • <b>PAM 600 Spray</b> • 8H2 513 00 A / 27.11.00	1
ACH 0365 • <b>Applicator</b> • 8H2 014 00 C / 12.10.98	2
GC 0236 • <b>Melting tank</b> • 8H2 012 10 A / 22.09.97	3
HC 0115 • <b>Redirecting valve</b> • 8H2 011 20 A / 20.04.98	4
GC 0170 • <b>Tank shutter</b> • 9H2 011 30 B / 20.04.98	5
FC 0210 • <b>Spiral spray head</b> • 8H6 002 20 A / 20.04.98	6
FCH 0211 • <b>Wide spray head</b> • 8H6 002 30 B / 21.01.98	7
H251310 • <b>Supply unit</b> • 8H2 513 10 B / 13.02.01	8
H711900 • <b>Heat control</b> • 8H7 119 00 A / 28.11.00	9
H301460 • <b>Air maintenance unit</b> • 8H3 014 60 A / 31.08.00	10

## Connection diagram

<b>Electrical connection diagram</b> • 8H7 020 21 A	11
<b>Pipe layout</b> • 8H3 010 10 A	12

### Ordering spare parts

 **Use only original spare parts!**

Please give us following figures when ordering spares:

- Type of tool      PAM 600 Spray
- Code-No.
- Part name
- Quantity

Changes reserved



**Fastening Technology Inc.**

2120 Gateway Blvd., Charlotte N. C. 28208  
 P.O. Box 669063, Charlotte N.C. 28266  
 Tel. (704) 394 3141, Tfx. (704) 394 9339