



Pos. #	Attachment # Description	ABS0013C/ 1"-2" Screws	ABS0222C/ 1"-3" Screws
		Part #	Part #
1	Depth Control	BGS0081	BGS0083
2	Depth Control Screws (2x)	KFS0060	KFS0060
3	Gear Wheel Unit	FXS0008	FXS0008
4	Screw with Roller	KFS0004	KFS0004
5	Gliding Piece	EXS0070	EXS0060
6	Spring	NFS0227	NFS0305
7	Curve	HAS0010	HAS0013
8	Spring Guide	KBS0015	KBS0015
9	Screw for belt guide (2x)	NAS0176	NAS0176
10	Belt Guide Rail Only	DXS0043	DXS0043
11	Bolt with Threads	KDS0065	KDS0065
12	Plastic Handle for Belt Guide	BCS0004	BCS0004
13	Wing Nut Screw	KFS0066	KFS0066
14	Allen Key Set	BZS0002	BZS0002
15	Adapter	Motor Specific (see motor guide)	Motor Specific (see motor guide)
16	Bit Holder	Motor Specific	Motor Specific
17	Depth Control Ring	GXS0010	GXS0010
18	#2 x 140mm Phillips Bit 140mm PAMDrive Bit #2 x 120mm Phillips Bit 120mm PAMDrive Bit	BITP2120 BITD2120	BITP2140 BITD2140
19	Pin for Gear Wheel Unit	KDS0022	KDS0022
20	Extension Pole Tube	Not Normally used	Motor Specific
21	Dedicated Inner Rod	Not Normally used	BHS0208
22	Housing complete with back plate and curve	CXS0016	CXS0064
23	Extension Pole Set Screws (2x)	Not Normally used	NASS0394
24	Screw for Curve (rear)	NAS0420	NAS0420
24a	Screw for curve (front)	KDN0578	NAS0426
25	Extension Pole Handle	n/a	BCS0011
26	Motor	Not included	Not included



Schematic for PAM Autofeed Tools

Motor Guide

Motor	Adapter/Bit Holder	Extension Pole/Inner Rod
Makita 6823/6824/6825	BAS0248/BDS0012	BHS0251/BHS0208
Makita 6827	BAS0246/BDS0012	n/a
Milwaukee 6740-20/6703-20	BAS0266/BDS0012	BHS0218/BHS0208
DeWalt DW272/DW276	BAS0268/BDS0012	BHS0224/BHS0208
Hitachi *	BAS0247/BDS0012	BHS0249/BHS0208

*earlier models may require different extension poles

ABS0013C and ABS0222C includes parts in Positions 1-13, 19, 22, 24, and 24a. All other parts shown for informational purposes to indicate attachment with which they are to be used.

Note: DeWalt adapters designed for 1"-2" screws only.